


## PVCu Plaster Stop Beads

Used on door and window openings also at base of wall and ceiling level.

Designed to deliver a clean edge, they protect and finish plaster and render edges.

PVCu Plaster Stop Beads						
PPS03	PPS06	PPS08	PPS10	PPS15	PPS20	PWW15
3 - 4 depth mm	6 - 8 depth mm	8 - 10 depth mm	10 - 12 depth mm	15 - 17 depth mm	20 - 22 depth mm	15 depth mm
50 per box	50 per box	50 per box	50 per box	50 per box	50 per box	50 per box
T = 3mm	T = 6mm	T = 8mm	T = 10mm	T = 15mm	T = 20mm	T = 15mm
W = 27mm	W = 45mm	W = 45mm	W = 45mm	W = 45mm	W = 45mm	W = 58mm
L = 2.5m	L = 2.5m	L = 2.5m	L = 2.5m	L = 2.5m	L = 2.5m	L = 2.5m

Suitable for Internal and External use



The most appropriate Catnic bead should be chosen to suit the application, required plaster depth and the desired finish.

Application and installation should be in accordance with BS 5492:1990 Code of Practice for internal plastering and BS 5262:1991 Code of Practice for external renderings. Catnic PVCu plaster beads conform to BS EN 13914-1:2005 and are manufactured from virgin polyvinylchloride unplasticized, which is impact resistant, external window grade and UV stable.

### Benefits of PVCu beads:

- Precision engineered perforation pattern
- 0.25mm high ribs at regular intervals
- Pro-Grip™ adhesion system for a stronger bond
- Withstands most site damage, non corrosive & unaffected by weathering
- Impact resistant, lightweight and safe handling

Catnic PVCu plaster beads have been designed to be used externally where galvanised beads are not recommended, and internally in areas where high moisture or damp exist. A great range of colours offer a variety of finish effects:

### Catnic

Pontypandy Industrial Estate  
Caerphilly  
CF83 3GL  
T: 029 2033 7900  
F: 029 2086 7796

01/2015

### Application:

Fix beads simply in one of the following ways:

1. Using stainless steel nails (compatible with bead material) complying with BS 1202:Part 1, fixed at a maximum of 600mm apart. When nailing to a solid background the line of the bead will follow the line of the background.
2. Press the bead onto dabs of the same material as the undercoat; dabs should be applied at a maximum of 600mm apart. This method will even out minor irregularities in the line of the background, although the line of the bead will tend to generally follow the line of the background.
3. When beads are used with metal lath backgrounds, stainless steel tying wire may be used to secure the beads in position. Soft stainless steel wire complying with BS 1554 should be used to match the bead and lath materials. All wires should be twisted tightly and the ends bent away from the finished face of the coating.

Beads may be trimmed to length using fine toothed hacksaw or tin snips. PVC pipe weld adhesive can be used for butt joints in conjunction with link pegs where required.



White  
RAL 9003



Ivory  
RAL 1015



Terracotta  
RAL 8203



Grey  
RAL 7037



Brown  
RAL 8014



Black  
RAL 9005

Needs another colour?  
Supply us with a RAL number  
and we can match it\*

\*Terms and conditions apply.

[www.catnic.com](http://www.catnic.com)

Care has been taken to ensure that the contents of this publication are accurate, but Tata Steel Europe Limited and its subsidiaries, which includes Tata Steel UK Limited, do not accept responsibility or liability for errors or information that is found to be misleading. Before using products or services supplied or manufactured by Tata Steel Europe Limited and its subsidiaries, customers should satisfy themselves as to their suitability.

© Copyright 2015 Tata Steel UK Limited.